by graham-field

Matrix series



To avoid personal injury or damage to bed, read all sections pertaining to the bed model before use.

FDA Recognized Standard: ANSI/AAMI STD ES60601-1

Health Canada Recognized Standard: CAN/CSA C22.2 No. 60601-1 (IEC 60601-1:2012-Ed.3.1)

Includes International Standards: IEC 60601-1, IEC 60601-1-2, IEC 60601-2-52

EMC Standard: IEC60601-1-2 Ed. 4.0



TABLE OF CONTENTS

IMPORTANT SAFETY AND WARNING INFORMATION	3
IMPORTANT SAFETY AND WARNING INFORMATION	4
ELECTROMAGNETIC COMPATIBILITY (EMC) INFORMATION	4
ENTRAPMENT AND COMPLIANCE INFORMATION	
RECOMMENDED MAINTENANCE	6
MECHANICAL AND ELECTRICAL INFORMATION	7
OPERATING CONDITIONS	/
STORAGE AND TRANSPORT CONDITIONS	
DISPOSAL OF EQUIPMENT AND ACCESSORIES	
BED SETUP AND OPERATION INSTRUCTIONS	9
UNPACKING THE BED (MATRIX 4000 SERIES SHOWN)	9
HEADBOARD AND FOOTBOARD ASSEMBLY / INSTALLATION	
STANDARD MATTRESS RETAINER INSTALLATION	14
MATRIX 4000 / 6000 SERIES WIREFORM WALLSAVER INSTALLATION	15
MATRIX 4000 / 6000 SERIES — OPERATING THE CASTER PEDAL LOCK MECHANISM	
MATRIX 5000 SERIES WIREFORM WALLSAVER INSTALLATION	16
PLUGGING IN THE FOOTBOARD STAFF CONTROL	17
MATRIX SERIES OPTIONAL ACCESSORIES	18
MATRIX SERIES HAND CONTROL PENDANT OPERATION	
BED OPERATION - OPTIONAL STAFF CONTROL PANEL *	25
BED OPERATION - CHAIR POSITION	
BED OPERATION - TRENDELENBURG / REVERSE TRENDELENBURG POSITION	27
MATRIX 5000 SERIES BED OPERATION — STATIONARY / LOW ROLL POSITIONING	28
TROUBLESHOOTING	24
NOTHING WORKS — NO POWER	
AUDIBLE SYSTEM WARNING (INTERMITTENT BEEP)	
KNEE DOESN'T LOWER, AUDIBLE SOLID BEEP WARNING	
GENERAL TROUBLESHOOTING QUICK REFERENCE	
GENERAL IROUBLESHOOTING QUICK REFERENCE	33
I IMITED WARRANTY	34

These Instructions for Use cover the Matrix Series with Standard and Advanced Positioning (APS), Standard Casters and Pedal-Lock option, for 35" and 42" Wide beds.

The Matrix Series is designed for Adult Patient and Caregiver use.

To order Matrix Series Bed service parts, contact a GF Health Products, Inc. customer service representative at 1-770-368-4700. For a list of Matrix Series bed service parts, visit www.grahamfield.com.

To order a Matrix Series bed or accessories, contact a GF Health Products, Inc. sales representative at 1-770-368-4700.

Important Notice: Check all parts for shipping damage and test before using. In case of damage, DO NOT USE — contact qualified service personnel for examination and repair.

LABEL SYMBOL DEFINITIONS



Consult
Accompanying
Documents



Safe Working Load



Double Insulated



Protected Grounded Device



Type B Equipment and Applied Parts



Follow Instructions for Use



IMPORTANT SAFETY AND WARNING INFORMATION



This product is a variable height, adjustable mattress platform. The expected service life of this product is fifteen years. Beds manufactured by Basic American Medical Products are designed for use within an institutional healthcare environment (i.e. assisted living, skilled nursing, transitional care, rehabilitation care, Environment (3), as defined in IEC60601-2-52 Safety Standard.).



The maximum safe working load for the Matrix series bed, including bedding, resident / patient, support surface, and accessories, is 450 lb (204.1 kg), with weight evenly distributed, and maximum patient weight is 400 lb (181.4 kg). Accessory weights follow:

ACCESSORY DESCRIPTION	WEIGHT
Extension Kit, Standard Width	12 lb (5.4 kg)
Extension Kit, Wide	14 lb (6.4 kg)
Trapeze Adapter	13 lb (5.9 kg)
Trapeze	16 lb (7.3 kg)
Half Counter-Rotating Assist Device (Set of 2)	21 lb (9.5 kg)
Fixed Assist Bar, Head	6 lb (2.7 kg)
Pivoting Assist Bar	10 lb (4.5 kg)



WARNING: To avoid risk of electric shock, this equipment must be connected to a supply mains with protective earth (i.e. a grounded outlet).



DO NOT open assemblies such as the Actuators, Hand Control Pendant, or Control Box. If unauthorized personnel perform work on these components, the manufacturer's warranty becomes void.



DO NOT use unauthorized parts, accessories, or adapters other than those specified / authorized by GF Health Products, Inc.



When operating the HI/LO, Knee, or Back Functions of the bed, ALWAYS ensure the confined individual is positioned properly within the confines of the bed. DO NOT let any extremities protrude over the side or between the bed rails when performing these functions.



The bed should be lowered to lowest position when resident is left unattended. DO NOT lower the bed when objects are beneath it. Failure to inspect under the bed can result in personal injury or property damage.



The bed's Hand Control Pendant Cable MUST BE ROUTED AND SECURED PROPERLY to ensure it does not become entangled and eventually severed during use. Also ensure electrical cords DO NOT get tangled around the bed, side rails, or legs during transport or normal operation of the bed.



When using nasal-type or masked-type administering equipment, all oxygen or air tubing MUST BE ROUTED AND SECURED PROPERLY to ensure the tubing does not become entangled and eventually severed during the normal operation of the bed.



Keep all moving parts free of obstructions (i.e. blankets / sheets, heating blankets / pads, wiring, etc.).



DO NOT use the assist devices as push handles for moving the bed. Assist devices can be deformed or broken if excessive side pressure is exerted. Assist devices are not meant for patients considered high risks for entrapment (i.e. patients with pre-existing conditions such as confusion, restlessness, lack of muscle control, altered mental status, either organic or medicinal, or a combination thereof). Additional safety measures should be considered for such high-risk patients.



NEVER permit more than one person on / in the bed at any time.



Body weight should be evenly distributed over the sleeping surface of the bed. DO NOT allow the patient to lie, sit, or lean in such a way that their entire body weight is placed only on the raised head or foot section of the bed. This especially applies when repositioning or transferring a patient in or out of the bed. Increased risk may occur when the patient's size and / or weight are inappropriate for the bed's dimensions or weight capacity.



Risk of entanglement or injury may occur if the mattress used with mattress retainers does not fill the entire width between stops or which compresses to less than 1.50 inches under user's weight.



Mattress must be properly sized to fit the mattress support platform and must remain centered on the support platform relative to State and Federal guidelines. Recommended minimum dimensions of mattress are 35-36 inches wide and 6 inches deep. Length and width should match the mattress support platform. Use of an improperly fitted mattress could result in injury or death. Standard mattresses are 35 inches wide and 6 inches deep, and wide mattresses are 42 inches wide and 6 inches deep.



IMPORTANT SAFETY AND WARNING INFORMATION



IMPORTANT: Powered air mattress surfaces may pose a risk of entrapment. Prior to use, ensure the therapeutic benefits outweigh the risk of entrapment.



The bed is intended for use within a temperature range of 10°C to 40°C. It has a water resistance rating of IPX4 and IS NOT to be power washed or submerged. The bed may be cleaned as needed using an appropriate dilution of mild soap and water.



The head / back and knee / foot decks can be lifted freely by hand for easy cleaning access when patients are not in the bed. If you lift the head / back or knee / foot deck for any reason, take great care when lowering back down to the prone position - ensure all body parts are clear of the space between the deck and the bed prior to slowly lowering any deck manually. To avoid injury, DO NOT LET DECKS FALL FREELY FROM ANY ANGLE.



WARNING: Notice for California Customers - California Proposition 65 WARNING: This product can expose you to chemicals including DEHP which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov/product.



WARNING: ALWAYS position bed so that the power cord and plug are easily accessed.



Proper routing and tie-off of electrical cabling, especially the power cord, is essential for proper operation and to ensure safety from electrical shock. In the event you are replacing any electrical cabling on your bed, you must ensure the cables are free from pinch points, obstructions, or stretched so tight that they may come loose or become damaged. In addition, cables should be tied off in such a way to secure them and keep them free from tangling on any part of the bed during normal operation. Refer to pages 27 and 28 for proper cable routing.

ELECTROMAGNETIC COMPATIBILITY (EMC) INFORMATION



WARNING: Medical Electrical Equipment needs special precautions regarding EMC and needs to be installed and put into service according to the EMC information provided in this manual.



WARNING: Electronic equipment may be influenced by Radio Frequency (RFI). Caution should be exercised with regard to the use of portable communications in the area around such equipment. Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the bed including specified bed cables. Degradation of the performance of the bed could result.



IF RFI causes erratic behavior, unplug the electric bed immediately. Leave unplugged while transmission is in progress.



WARNING: The use of accessories, transducers, and cables other than those specified by the manufacturer may result in increased emissions or decreased immunity of the bed. GF Health cables and accessories include motor cables, mains cable, pendant cables, back up battery and cable, USB port cable and UBL and cable.



WARNING: This bed should not be used adjacent to or stacked with other equipment. If adjacent or stacked use with other equipment is necessary, this bed and the other equipment should be observed to verify that they are operating normally.



WARNING: The EMISSIONS characteristics of this equipment make it suitable for use in industrial areas and hospitals (CISPR 11 class A). If it is used in a residential environment (for which CISPR 11 Class B is usually required) this equipment might not offer adequate protection to radio frequency communication services. The user might need to take mitigation measures, such as relocating or reorienting the equipment.



ENTRAPMENT AND COMPLIANCE INFORMATION

On April 10, 2006, the FDA (U.S. Food and Drug Administration) released long-awaited guidelines for reducing the risk of bed entrapment: "Hospital Bed System Dimensional and Assessment Guidance to Reduce Entrapment". The new Guidance identifies potential entrapment areas and those body parts most at risk for entrapment; provides design criteria for manufacturers of new hospital/convalescent beds; recommends particular test methods to assess the conformance of existing hospital / convalescent bed systems; and answers frequently-asked questions about entrapment issues.

The new Guidance was a result of a long-standing collaboration between the FDA and the Hospital Bed Safety Workgroup (HBSW), formed in 1999. GF Health Products, Inc.'s Long Term Care Bed division: Basic American Medical Products, is an HBSW charter member. As a result of our commitment to product safety, all our current long-term care beds have been strictly tested and conform to the new FDA Guidance.

The guidelines set forth by the FDA Guidance lay out specific dimensional limitations on potentially injury-threatening gaps and spaces that can occur between bed system components, such as rails, when not properly installed. GF Health Products, Inc. and Basic American Medical Products have conformed to these guidelines from a manufacturing aspect. However, entrapment issues can often arise when a healthcare provider / facility has not correctly assembled the components on a bed. It is essential that the provider / facility fully understand their responsibility in complying to the guidelines set forth by the FDA in order to avoid injury. To that end, we have provided the FDA's web address at right as a resource for understanding and following these guidelines for the safety of patients / residents.

It is also essential to have the correct bed components / accessories that correspond with the needs of the patient / resident and the particular bed you have purchased. Matching the correct bed component that correlates with the regulatory guidelines can be a daunting task. Our sales team at GF Health Products, Inc. and our friendly Customer Service Representatives at Basic American Medical Products can help you sift through the wide array of compliance and bed options. We will help you determine which bed / bed part is best for the patient's / resident's particular needs and help you with any compliance issues.

The MATRIX series bed and accessories listed in these instructions are in full compliance with FDA guidelines for reducing the risk of bed entrapment: "Hospital Bed System Dimensional and Assessment Guidance to Reduce Entrapment".

Details can be found at www.fda.gov.



RECOMMENDED MAINTENANCE

Regular maintenance of the Long Term Bed is necessary to ensure continuing proper and safe operation. Read and observe the following recommended maintenance schedule. Additional Maintenance Log pages are available at the end of these instructions.


		COMMENICATION PE		MA	AINTEN	ANCE
ITEM	Inspect on Receipt	Every 3 Months	Every 6 Months	Performed by	Date	Comments
Maintenance Inspection of All Components at Receip	t of Shipm	ent				
Ensure all parts / components are included (see "Unpacking The Bed").	Х					
Check all bed components for obvious damage.	X					
Inspect the power cord for any cuts and / or damage.	Х					
Check to see all actuator / motor cables are routed and connected properly to the control box.	Х					
Mechanical Inspection of Assemblies						
Inspect all welds on the sleeping surface, frame, and base assemblies for stress fractures.			Х			
Inspect all fasteners for wear and looseness.			Х			
IMPORTANT: Lubricate all pivot points, actuator / motor clevis pins, and control arm clevis pins as needed. White Lithium Grease is recommended.			Х			
Mechanical Inspection of Casters and Pedal Locking	Mechanis	m				
Check the pedal locking mechanism to ensure it engages and disengages properly.		Х				
Check the casters and stationary foot pads on both the head end and foot end for any damage, wear, or debris. Replace if needed.		Х				
Check all rolling casters to ensure that they roll properly and are unobstructed.		Х				
Electrical Inspection of Control Box, Hand Control Pe	endant, an	d Staff Co	ntrol			
Check the external power cord that plugs into the control box for any chafing, cuts, or wear. Replace if damaged.		Х				
Ensure all attaching hardware is securely tightened.		Х				
Check all electrical connections for wear or fractures.		Х				
Check the external backup battery (if you have one). Replace if needed.		Х				
Check the hand control pendant cable for chafing, cuts, or wear.		Х				
Check all hand control pendant functions - check to ensure each button and associated function work properly (i.e. head section rises when the HEAD UP button is activated).		Х				
Electrical Inspection of Actuators / Motors						
Check the actuator / motor cables for any chafing, cuts, or wear.		Х				
Check the range of movement on all motors to ensure they do not bind in the Full Up or Full Down positions.		Х				



MECHANICAL AND ELECTRICAL INFORMATION

MATRIX SERIES-MECHANIC	CAL	NO	OTE: All dimens	sions are ±0.25	inches
Specification		4100 (35")	4100 (42")	5100 (35")	6100 (35")
Overall Bed Length (with boards and wallsaver)	76"	81.2"	81.2"	82.7"	81.2"
	80"	83.1"	83.1"	83.9"	83.1"
Sleep Deck Width		35"	42"	35"	35"
Bed Width Including Boards		36"	42"	36"	36"
Maximum Height (floor to top of mattress suppo	ort deck)	27"	27"	27"	27"
Minimum Height (floor to top of mattress suppo	ort deck)	8.95"	8.95"	8.95"	8.95"
Maximum Head / Back Deck Angle		68°	68°	68°	68°
Maximum Knee / Foot Deck Angle		25°	25°	25°	25°
Maximum Trendelenburg / Reverse Trendelenburg	ırg Angle	12°	12°	13°	12°
Maximum Safe Working Load WITH WEIGHT EVENLY DISTRIBUTED - includes bedding, resident / patient, support surface, and accessories		450 lb (204.1 kg)	450 lb (204.1 kg)	450 lb (204.1 kg)	450 lb (204.1 kg)
Bed Mass (without assist devices or boards)	150 lb (68.0 kg)	157 lb (71.2 kg)	157 lb (71.2 kg)	157 lb (71.2 kg)	
MATRIX SERIES-ELECTRIC	AL (A	ALL MOD	ELS)		
Power / Frequency	•	120 Volt / 50/	60 Hz		
Output Rating		24Vdc			
Maximum Amperage		4.0 Amps			
Classification		Class 1, Type B			
Power (Electrical) Cord		#18 AWG 3 Conductor Type SJT			
Mode of Operations		10% Max. Duty Cycle (2 minutes on / 18 minutes off)			ites off)
Battery Pack and Charger can be purchased so	eparately	as accessorie	S.		

TYPICAL MATRIX SERIES BED IDENTIFICATION LABELS with Grounded Electrical Cable



Bed labels are an important part of identifying the bed's make and model when ordering replacement parts. The Serial Number is essential if you are claiming parts or service under warranty. These helpful labels can be located on the main frame rails, immediately below the sleep decks on either side of the bed.

Have this IMPORTANT information ready when calling our Customer Service or Technical Support staff at 1-770-368-4700; it will allow us to better assist you and quickly answer your questions and concerns.



WARNING: Do not modify this equipment without authorization from GF Health Products, Inc.

NOTE: For Matrix Series Service Parts, Technical Assistance, and Information, call our Customer Service Department at 1-770-368-4700. For a list of Matrix Series bed service parts, visit www.grahamfield.com.



The following warning labels have been placed on the bed to help protect you and the bed from damage. Do not remove any labels from the bed.

WARNING!

DO NOT LOWER BED WHEN OBJECTS ARE BENEATH BED. FAILURE TO INSPECT UNDER BED CAN RESULT IN DAMAGE TO PROPERTY OR PERSONAL INJURY.

ATTENTION:

S'assurer de ne pas faire descendre le lit lorsque des objets se trouvent sous le lit. Ne pas inspecter le dessous du lit pourrait entrainer des dommages materiels et des risques de blessures.



WARNING!

DO NOT LOWER BED WHEN OBJECTS ARE BENEATH BED. FAILURE TO INSPECT UNDER BED CAN RESULT IN DAMAGE TO PROPERTY OR PERSONAL INJURY.

CAUTION

THIS BED IS SUITABLE FOR USE ONLY WITH OXYGEN ADMINISTERING EQUIPMENT OF THE NASAL OR MASK TYPE OR A TENT COVERING ONLY THE UPPER HALF (HEAD END) OF THE BED. OXYGEN TENT CANOPIES SHOULD NOT EXTEND BELOW BED SPRING LEVEL. LOCK HAND CONTROL AT FOOT OF BED WHEN USING OXYGEN ADMINISTERING EQUIPMENT.

WARNING:

Incompatible mattresses can create hazards. Read Instructions for use.

ATTENTION:

Matelas incompatibles peuvent créer des dangers.

Lisez les Instructions d'utilisation.

ATTENTION:

CE LIT PEUT ETRE UTILISE UNIQUEMENT AVEC UN EQUIPMENT DESTINE A L'ADMINISTRATION D'OXYGENE DE TYPE NASAL OU MASQUE OU AVEC UNE TENTE RECOUVRANT SEULEMENT LA MOTTIE AVENT (TETE) DU LIT. LES COTES DE LAS TENTE OXYGENE NE DOIVENT PAS SE PROLONGER PLUS DAS QUE LA SOMMIER DU LIT.

ENVIRONMENTAL SPECIFICATIONS

OPERATII	NG CONDITIONS
Ambient Temperature	10°C to 40°C
Relative Humidity	30% to 75% Non-Condensing
Atmospheric Pressure	700 hPa to 1060 hPa
Protected Against Splashing Water	IPX4

STORAGE AND TR	RANSPORT CONDITIONS
Temperature	-10°C to 50°C
Relative Humidity	20% to 90%
Atmospheric Pressure	700 hPa to 1060 hPa

DISPOSAL OF EQUIPMENT AND ACCESSORIES



Follow local governing ordinances and recycling plans regarding disposal of the device or components normally used in operation. The device does not generate waste or residue in operation. Any accessories not part of the device MUST be handled in accordance with the individual product marking for disposal.



BED SETUP AND OPERATION INSTRUCTIONS UNPACKING THE BED (MATRIX 4000 SERIES SHOWN)


- Ensure all parts / components are included.
- Check all bed components for obvious damage.
- Inspect the Power Cord for cuts or damage.
- Ensure all actuator / motor cables are routed and connected properly to the control box.

DISCARD

- 1) Foam Block (4)
- 2) Honeycomb Block (8)
- 3) Shipping Board (1)
- 4) Cable Tie (3) Cut and Discard KEEP
- 5) Panel Mount Kit
- 6) Mattress Retainer
- 7) Pendant Holster
- 8) Wireform Wallsaver

NOTE


END OF POWER
CORD IS COILED
FOR SHIPPING
AND TIED, WITH
CABLE TIE, TO GRID
WIRE WITH HAND
CONTROL PENDANT,
PENDANT CABLE AND
HOLSTER.






HEADBOARD AND FOOTBOARD ASSEMBLY / INSTALLATION MATRIX 4000 SERIES


MATRIX 4000 SERIES HEADBOARD INSTALLATION *



ITEM	QTY.	DESCRIPTION
1	2	BRACKET, BOARD MOUNTING RH
2	2	BRACKET, BOARD MOUNTING LH
3	2	CABLE TIES 12" NYLON
4	8	SCREW JCB-B 1/4-20 X 20MM HX FT BZ
5	4	5/16 x 1 1/2 CLEVIS PIN -ZI
6	4	1-9/16 HAIR PIN CLIP

- The headboard may come with four pre-installed inserts - if not already installed, assemble the four inserts into the outside of the headboard as shown above.
- 2. Position a right (#1) and left (#2) mounting bracket on the inside of the headboard with headboard mounting holes facing outward as shown above.
- 3. Align the bracket top holes with the headboard top holes.
- 4. Insert a screw (#4) through each of the top holes and bottom holes and screw into each insert. Tighten loosely (hand tight) until after brackets are fastened to the bed frame.






- 5. At the head deck end, slide the brackets into the main frame rail hollow ends.
- 6. **FOR 80" BEDS:** Slide the brackets in until the bracket hole aligns with the lower rail hole as shown above. 76" and 80" bracket labels will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 7. **FOR 76" BEDS:** Slide the mounting brackets in until the bracket hole aligns with the upper rail hole as shown above. Only 76" bracket label will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 8. Tighten screws with the hex key included in the kit.




MATRIX 4000 SERIES FOOTBOARD INSTALLATION



ITEM	QTY.	DESCRIPTION
1	2	BRACKET, BOARD MOUNTING RH
2	2	BRACKET, BOARD MOUNTING LH
3	2	CABLE TIES 12" NYLON
4	8	SCREW JCB-B 1/4-20 X 20MM HX FT BZ
5	4	5/16 x 1 1/2 CLEVIS PIN -ZI
6	4	1-9/16 HAIR PIN CLIP

- The footboard may come with four pre-installed inserts - if not already installed, assemble the four inserts into the outside of the footboard as shown above.
- 2. Position a right (#1) and left (#2) mounting bracket on the inside of the footboard with footboard mounting holes facing outward as shown above.
- 3. Align the bracket top holes with the footboard top holes.
- Insert a screw (#4) through each of the top holes and bottom holes and screw into each insert. Tighten loosely (hand tight) until after brackets are fastened to the bed frame.
- * For residents taller than 185 cm (6' 1"), a 4" Length Extension Kit is available. Please contact Customer Service for more information.




- 5. At the foot deck end, slide the brackets into the main frame rail hollow ends.
- FOR 80" BEDS: Slide the mounting brackets in until the bracket hole aligns with the first rail hole as shown above. 76" and 80" bracket labels will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 7. **FOR 76" BEDS:** Slide the mounting brackets in until the bracket hole aligns with the second rail hole as shown above. Only 76" bracket label will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 8. Tighten screws with the hex key included in the kit.




MATRIX 5000 / 6000 SERIES


MATRIX 5000 / 6000 SERIES HEADBOARD INSTALLATION *



ITEM	QTY.	DESCRIPTION
1	2	BRACKET, BOARD MOUNTING RH
2	2	BRACKET, BOARD MOUNTING LH
3	2	CABLE TIES 12" NYLON
4	8	SCREW JCB-B 1/4-20 X 20MM HX FT BZ
5	4	5/16 x 1 1/2 CLEVIS PIN -ZI
6	4	1-9/16 HAIR PIN CLIP

- The headboard may come with four pre-installed inserts - if not already installed, assemble the four inserts into the outside of the headboard as shown above.
- 2. Position a right (#1) and left (#2) mounting bracket on the inside of the headboard with headboard mounting holes facing outward as shown above.
- 3. Align the bracket top holes with the headboard top holes.
- Insert a screw (#4) through each of the top holes and bottom holes and screw into each insert. Tighten loosely (hand tight) until after brackets are fastened to the bed frame.






- 5. At the head deck end, slide the brackets into the main frame rail hollow ends.
- 6. FOR 80" BEDS: Slide the brackets in until the first bracket hole aligns with the upper rail hole as shown above. 76" and 80" bracket labels will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 7. **FOR 76" BEDS:** Slide the mounting brackets in until the second bracket hole aligns with the upper rail hole as shown above. Only 76" bracket label will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 8. Tighten screws with the hex key included in the kit.





MATRIX 5000 / 6000 SERIES FOOTBOARD INSTALLATION



ITEM	QTY.	DESCRIPTION
1	2	BRACKET, BOARD MOUNTING RH
2	2	BRACKET, BOARD MOUNTING LH
3	2	CABLE TIES 12" NYLON
4	8	SCREW JCB-B 1/4-20 X 20MM HX FT BZ
5	4	5/16 x 1 1/2 CLEVIS PIN -ZI
6	4	1-9/16 HAIR PIN CLIP

- The footboard may come with four pre-installed inserts - if not already installed, assemble the four inserts into the outside of the footboard as shown above.
- 2. Position a right (#1) and left (#2) mounting bracket on the inside of the footboard with footboard mounting holes facing outward as shown above.
- 3. Align the bracket top holes with the footboard top holes.
- Insert a screw (#4) through each of the top holes and bottom holes and screw into each insert. Tighten loosely (hand tight) until after brackets are fastened to the bed frame.
- * For residents taller than 185 cm (6' 1"), a 4" Length Extension Kit is available. Please contact Customer Service for more information.






- 5. At the foot deck end, slide the brackets into the main frame rail hollow ends.
- 6. FOR 80" BEDS: Slide the mounting brackets in until the bracket hole aligns with the first rail hole as shown above. 76" and 80" bracket labels will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 7. **FOR 76" BEDS:** Slide the mounting brackets in until the bracket hole aligns with the second rail hole as shown above. Only 76" bracket label will be visible. Pin brackets to frame with Clevis Pins and Hair Pins provided.
- 8. Tighten screws with the hex key included in the kit.



STANDARD MATTRESS RETAINER INSTALLATION USING 35" OR 42" WIDTH MATTRESS RETAINER



The Matrix Series Bed mattress retainer was designed to span the width of the sleeping surface.

<u>One</u> retainer is shipped with the Matrix 4000 and will fit on the Foot End as shown (*Note: An optional retainer can be ordered separately for the head end of the Matrix 4000 Series beds*).

Two retainers, one for each end, are shipped with the Matrix 5000 / 6000.

- 1. Determine if you need to position your bed in an 80" or 76" configuration (80" length bed = outside holes; 76" length bed = inside holes).
- 2. Carefully squeeze the Mattress Retainer ends inward, toward the center of the retainer, and insert the ends into the proper holes. Lay the Mattress Retainer down so that the elbows rest on the decks and the long cross rod faces away from the bed as shown.

IMPORTANT: Ensure all three adjustable parts are properly positioned for 76" or 80" configurations (see pages 10, 11, 12, 13 and 15).



Be sure to use a mattress that is properly sized to fit the sleep deck, which will remain centered on the deck relative to State and Federal Guidelines. Use of an improperly fitted mattress could result in injury or death.



Use a properly sized mattress in order to minimize the gap between the side of the mattress and assist devices. This gap must be small enough to prevent resident / patient from getting their head or neck caught in this location.




MATRIX 4000 / 6000 SERIES WIREFORM WALLSAVER INSTALLATION

WALLSAVER ASSEMBLY

- Position the Wireform Wallsaver with bent end facing upward and tab ends facing inward as shown at right.
- 2. Determine the position desired (see WALLSAVER POSITIONS below).
- Gently squeeze the wallsaver tab ends inward toward the center of the wallsaver and, holding the tabs parallel with the caster base holes, slide the tabs into the holes while letting the wallsaver gently expand outward.
- 4. Turn the wallsaver downward until it rests on the floor.

WALLSAVER REMOVAL

- To remove or move the wallsaver to a new position, raise the wallsaver off the floor until the end tabs are horizontal.
- Squeeze the ends toward the center of the wallsaver until the end tabs slide out of the caster base holes.



WALLSAVER POSITIONS

There are two positions for the Matrix series wallsaver. Holes nearest the center of the bed are for both 76" and 80" beds, and the holes closest to the head end are for use when a Trapeze Adapter is added to the bed.

The Standard Wallsaver will prevent the bed from making contact with the wall in all positions except Trendelenburg. If the *Advanced Positioning* (APS) bed is to be used in Trendelenburg position, the Trendelenburg Wallsaver must be used to prevent the bed from making contact with the wall.

A Trendelenburg Wallsaver is available when the bed is ordered with a Staff Control with Advanced Positioning.

MATRIX 4000 / 6000 SERIES — OPERATING THE CASTER PEDAL LOCK MECHANISM

LOCKED POSITION

To lock the foot end casters, step on the red pedal until the caster lock engages.

UNLOCKED POSITION

To unlock the foot end casters, step on the green release pedal until the caster lock disengages.




FOOT END of Matrix 4000 Series Bed Shown with Pedal Lock Engaged (RED DOWN = LOCKED POSITION)



MATRIX 5000 SERIES WIREFORM WALLSAVER INSTALLATION

WALLSAVER ASSEMBLY



- 1. Position the Wireform Wallsaver with bent end facing upward and tab ends facing inward as shown above.
- 2. Determine the position desired (see **WALLSAVER POSITIONS** below).
- 3. Gently squeeze the wallsaver tab ends inward toward the center of the wallsaver and, holding the tabs parallel with the caster base holes, slide the tabs into the slots while letting the wallsaver gently expand outward.
- 4. Turn the wallsaver downward until it rests on the floor.

WALLSAVER REMOVAL

- 1. To remove or move the wallsaver to a new position, raise the wallsaver off the floor until the end tabs are horizontal.
- 2. Squeeze the ends toward the center of the wallsaver until the end tabs slide out of the caster base slots.

WALLSAVER POSITIONS

- The Matrix 5000 Series wallsaver features two standard positions for easy bed / mattress length reconfigurations 76" and 80".
- 2. For 76" beds, position the wallsaver ends in the BACK caster base slots (toward the foot end). For 76" beds using an optional Trapeze unit, position the wallsaver ends in the FRONT caster base slots (toward the head end.)
- 3. For 80" beds, position the wallsaver ends in the FRONT caster base slots (toward the head end).
- 4. If you plan to use an optional Trapeze unit for an 80" length bed configuration, you will need to order a separate "custom wallsaver" in order to have the correct depth to protect your walls.



PLUGGING IN THE FOOTBOARD STAFF CONTROL

STEP 1 - ATTACHING THE FOOTBOARD

The Matrix series bed features a footboard Staff Control; however, the footboard is ordered separately with your bed because of the variety of board styles available. If ordered at the same time as the bed, the Staff Control Assembly and Shroud Cover will be pre-installed to the Footboard at the factory.

STEP 2 - CONNECTING THE CABLES: REFER TO DETAIL A AT RIGHT

a) Insert the T-Cable end (extending out the foot end with phone jack) into the round plug, making sure the phone jack is seated correctly inside the female plug (arrow to arrow – see DETAIL A at right and photos below).





Improper Connection (not completely seated)




Proper Connection (completely seated)


b) Screw on the round lock cap onto the Staff Control female plug to secure as shown above.




MATRIX SERIES OPTIONAL ACCESSORIES

MATRIX 4100 SERIES ONLY OPTIONAL ACCESSORIES












MATRIX 5100 / 6100 SERIES ONLY OPTIONAL ACCESSORIES










MATRIX 4100 / 5100 / 6100 SERIES OPTIONAL ACCESSORIES






















ZL90000












MATRIX SERIES HAND CONTROL PENDANT OPERATION



HAND CONTROL PENDANTOPERATION		
BUTTON	FUNCTION	
1	HEAD DECK ANGLE UP	
2	HEAD DECK ANGLE DOWN	
3	HI/LO UP (RAISE ENTIRE BED)	
4	HI/LO DOWN (LOWER ENTIRE BED)	
5	KNEE AND FOOT DECK ANGLE UP	
6	KNEE AND FOOT DECK ANGLE DOWN	
7	SET TO CHAIR POSITION	
8	UNDO CHAIR POSITION	
9	REVERSE TRENDELENBURG POSITION	
10	TRENDELENBURG POSITION	
11	OPTIONAL UNDERBED LIGHT	


NOTE:

The MATRIX Series Hand Control Pendant can be plugged into the T-Cable plugs on either side of the bed for easy access. The opposite side of the T-Cable should always have the provided cap attached for safety.


The two vertical ends of the double T-Cable run toward the foot end of the bed, with one vertical end plugging directly into the control box (or optional Underbed Light if your bed has that feature) and the other longer end runs along the tie rod and extends out the foot end and plugs into the Staff Control cable.



BED OPERATION - OPTIONAL STAFF CONTROL PANEL*



Press "Underbed Light" button (#14) to turn underbed light on or off.




Press "Head", "Knee", or "Chair" and "Key" at the same time to unlock individual lock out functions.

1	ALL LOCKED BUTTON
2	HEAD DECK UP BUTTON
3	HEAD DECK DOWN BUTTON
4	KNEE & FOOT DECK UP BUTTON
5	KNEE & FOOT DECK DOWN BUTTON
6	CHAIR POSITION BUTTON
7	UNDO CHAIR POSITION BUTTON
8	KEY LOCK/UNLOCK BUTTON
9	HI/LO (T/TR) LOCKED BUTTON
10	HI/LO UP BUTTON
11	HI/LO DOWN BUTTON
12	TRENDELENBURG
13	REVERSE TRENDELENBURG
14	UNDERBED LIGHT BUTTON

LOCK OUT SINGLE FUNCTIONS

To individually lock out the "Head", "Knee", "Chair", and "HI/LO" functions, press the appropriate top icon (#2, 3, 4, 10, or 12) button and the "Key" button at the same time. An orange LED lock symbol will appear under the related icon.


To "Unlock" any of the individual functions, press the top icon (#2, 3, 4, 10, or 12) and the "Key" Button (#8) simultaneously. LED lights will <u>not</u> show up.



LOCK OUT HI/LO FUNCTIONS

To lock out the functions for raising and lowering the entire bed and tilting the bed for Trendelenburg positions, press the "HI/LO Locked" (#9) button. Orange LED lock symbols will appear under the HI/LO and Trendelenburg icons.

To "Unlock" all HI/LO functions, press the "HI/LO Locked" button (#9) and the "Key" button (#8) simultaneously. Orange LED lights will not show up.



LOCK OUT EVERYTHING

To lock out all functions, press the "All Locked" button (#1). Orange LED lock symbols will appear under the "Head", "Knee", "Chair", "HI/LO", and "Trendelenburg/Reverse Trendelenburg" icons.

To "Unlock" all functions, press the "All Locked" button (#1) and the "Key" button (#8) simultaneously. Orange LED lights will <u>not</u> show up.





Staff Control with Advanced Positioning functions is shown above. Staff Control with Standard Positioning functions is shown at left; all standard functions operate the same as those defined above.

the same time to unlock all functions.



BED OPERATION - CHAIR POSITION








BED OPERATION - TRENDELENBURG / REVERSE TRENDELENBURG POSITION

- Ensure the Staff Control HI/LO function is not locked out (orange lock icon). To unlock, simultaneously press Key 1 and HI/LO Locked button 2.
- 2. To move the bed to Trendelenburg position (foot end up), press button 3.
- 3. To move the bed to Reverse Trendelenburg position (head end up), press button 4.






Matrix 4000 Shown






MATRIX 5000 SERIES BED OPERATION — STATIONARY / LOW ROLL POSITIONING


The Matrix 5000 Series is sold as a "Low Roll" bed, giving the user the option of placing it in a stationary (non-moving) position or lowering it into a "low roll" position. This is accomplished by lowering the bed until the stationary foot pads rise off the floor and the rolling casters contact the floor surface for easy mobility.








MATRIX 4000 SERIES ELECTRICAL CABLING





MATRIX 5000 / 6000 SERIES ELECTRICAL CABLING





TROUBLESHOOTING

NOTHING WORKS — NO POWER

- 1. Verify the outlet is supplying power.
- 2. Ensure the power cord is not pinched, frayed, or damaged in any way. Replace the Power Cord if damaged.
- Ensure all power cord, T-Cable, Hand Control Pendant, and Control Box receptacles and plugs are seated and fully inserted.
- 4. Ensure the Staff Control does not have functions locked out.
- 5. Plug the Hand Control Pendant directly into the Control Box. If the bed works, replace the T-Cable.

- Replace the Hand Control Pendant with a known good operating Pendant. If the bed works, replace the Hand Control Pendant.
- 7 If the bed still isn't functional after steps 1-6, replace the Control Box.
- 8. New Control Box installation will require motor Initialization.

NOTE: Service Control Box Motor Initialization Procedure as well as detailed troubleshooting and service instruction can be found at <u>www.grahamfield.com</u>.

AUDIBLE SYSTEM WARNING (INTERMITTENT BEEP)

NOTE: A function that is faulty or has lost motor position will cause the Control Box to beep intermittently when the faulty function's Hand Control Pendant button is depressed. All buttons depressed after the error function will also be non-functional and will cause a Control Box beep. If equipped with a Staff Control, the staff icons will also flash to indicate a system error.

When the Audible Beeping Error signal is heard:

- On the Hand Control Pendant, simultaneously press and hold both the HI/LO UP and HI/LO DOWN buttons (the Control Box should start beeping) for approximately five seconds until beeping stops.
- Reinitialize the motors by lowering the bed completely. In the following order, press the Hand Control Pendant buttons until the motors stop:
 - a. HI/LO DOWN
 - b. HEAD DECK ANGLE DOWN
 - c. KNEE AND FOOT DECK ANGLE DOWN

- This lowering of the motors will reset the system and should resolve minor synchronization or position lost issues. Check the bed functionality.
- If an audible error beep occurs during reset lowering of a function or while checking functionality, the function that initiated the beep is faulty.
- 5. After the faulty function initiates the beep, all other button functions will cause a beep and become non-functional.
- To operate and use the other good functions, perform step 1 again to reset the system.
- Reinitialize the motors as in Step 2 but only lower the motors that did not initiate the audible error beep.
- 8. These functions will operate normally until the faulty function button is pressed again.

NOTE: If the issue is not resolved, go to <u>www.grahamfield.com</u> for more detailed troubleshooting and service instructions.



KNEE DOESN'T LOWER, AUDIBLE SOLID BEEP WARNING

NOTE: As a result of the bed's programmed capability to achieve APS positioning, the Knee Motor will not lower if the HI/LO motors are not level. This is a safety measure to prevent the patient from sliding out of bed while in Chair Position.

The control box will emit a solid beep warning when attempting to lower the knee if this condition is present.

NOTE: This condition can also happen with beds not equipped with APS positioning or if the frame appears to be visually level. If the solid beep is present when trying to lower the knee:


- Return the bed frame to a level position by pressing the Hand Control Pendant UNDO CHAIR button until the bed is level. Continue holding the button down until the knee retracts.
- If not equipped with chair function, or if step 1 did not resolve the issue, lower the bed completely: press the *HI/LO DOWN* button until the motors shut off.
- 3. Now lower the knee using the **KNEE AND FOOT DECK ANGLE DOWN** button.

NOTE: If the issue is not resolved, go to <u>www.grahamfield.com</u> for more detailed troubleshooting and service instructions.



GENERAL TROUBLESHOOTING QUICK REFERENCE

NOTE: Advanced Service Troubleshooting Procedures, Flow Charts and Service Components can be found at www.grahamfield.com.



Plugs and Receptacles:

Loose plug connections or incorrect plug positioning will result in erroneous or no system error signals and faulty operation.

Before troubleshooting, ensure all plugs are engaged fully in their receptacles and located in the correct ports.



Motors

Test any motor by plugging it into a known good Control Box port.

Example: If the head motor is not functioning and the knee motor is functional, plug the

head motor into the knee Control Box port and operate the head motor with the knee Pendant button. If the head motor operates, it is good. If not working in the good port, replace the head motor or motor cable.

Motor Cables

Motor cables are interchangeable. Test a motor cable by attaching it to a known good motor and known good Control Box port and operating it.

T-Cables

Test a T-Cable by unplugging it from the Control Box port and plugging the Hand Control Pendant directly into the Control Box. If the bed functions with the Hand Control Pendant, replace the T-Cable.

Hand Control Pendants

Test a Hand Control Pendant by replacing it with a known good Pendant. If the Bed now operates, replace the Hand Control Pendant.

Staff Controls

Test a Staff Control by replacing it with a known good Staff Control. If the Bed now operates, replace the Staff Control.

Control Box

Test a Control Box by replacing it with a known good Control Box. If the bed now operates, replace the Control Box. If a known good Control Box is not available, go to www.grahamfield.com for detailed Troubleshooting Procedures.



LIMITED WARRANTY

SCOPE OF WARRANTY

GF Health Products, Inc. ("GF") warrants to the original purchaser only that it will replace or repair components, at GF's sole discretion, that are defective in material or workmanship under normal use and service. All warranties are conditioned upon the proper use of the products strictly in accordance with good commercial practice and applicable GF instructions and manuals, including proper use and maintenance. To the extent that a component is warranted by a third party, GF conveys all of its rights under that warranty to the original purchaser, to the extent permitted.

This limited warranty shall only apply to defects that are reported to GF's customer service team within the applicable warranty period and which, upon examination by GF or its authorized representative, prove to be a warranty item. This limited warranty is not transferable.

The warranted components and time period are set forth below:

Main Frame and welds:

Control Box and Actuator Motors:

Hand Control Pendant, Staff Control, and Cabling
Headboard and Footboard

All other durable components not listed above:

fifteen years
four years
three years
one year
two years

Subsequent service parts under warranty until the original warranty set forth above expires, or for one year, whichever is greater.

The applicable warranty period shall commence from date of shipment to the original customer, unless there is an expiration date on the component in which case the warranty shall expire on the earlier of warranty period or the expiration date.

OBTAINING WARRANTY SERVICE

A GF Customer Service Representative must authorize warranty service. Please contact the GF Customer Service department by calling 1-770-368-4700, sending a fax request to 1-770-368-2386 or by e-mailing a request to cs@grahamfield.com. Specific directions will be provided by the Customer Service Representative. Failure to abide by the specific directions will result in denial of the warranty claim.

EXCLUSIONS

The warranty does not cover and GF shall not be liable for the following:

- 1) Defects, damage, or other conditions caused, in whole or in part, by misuse, abuse, negligence, alteration, accident, freight damage, tampering or failure to seek and obtain repair or replacement in a timely manner;
- 2) Products which are not installed, used, or properly cleaned and maintained as required in the official manual for the applicable product;
- 3) Products considered to be of a non-durable nature including, but not limited to: casters, filters, fuses, gaskets, lubricants, and charts;
- 4) Accessories or parts not provided by GF;
- 5) Charges by anyone for adjustments, repairs, replacement parts, installation or other work performed upon or in connection with such products which are not expressly authorized in writing, in advance, by GF;
- 6) Any labor or shipping charges incurred in the replacement part installation or repair;
- 7) Costs and expenses of regular maintenance and cleaning; and
- 8) Representations and warranties made by any person or entity other than GF.



ENTIRE WARRANTY, EXCLUSIVE REMEDY AND CONSEQUENTIAL DAMAGES DISCLAIMER

THIS WARRANTY IS GF'S ONLY WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. GF MAKES NO IMPLIED WARRANTIES OF ANY KIND INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IF ANY MODEL OR SAMPLE WAS SHOWN TO THE CUSTOMER, SUCH MODEL OR SAMPLE WAS USED MERELY TO ILLUSTRATE THE GENERAL TYPE AND QUALITY OF THE PRODUCT AND NOT TO REPRESENT THAT THE PRODUCT WOULD NECESSARILY CONFORM TO THE MODEL OR SAMPLE IN ALL RESPECTS.

THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PARTS. GF SHALL NOT BE LIABLE FOR AND HEREBY DISCLAIMS ANY DIRECT, SPECIAL, INDIRECT, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO: DAMAGES FOR LOSS OF PROFITS OR INCOME, LOSS OF USE, DOWNTIME, COVER, OR EMPLOYEE OR INDEPENDENT CONTRACTOR WAGES, PAYMENTS AND BENEFITS.

The warranties contained herein contain all the representations and warranties with respect to the subject matter of this document, and supersede all prior negotiations, agreements and understandings with respect thereto. The recipient of this document hereby acknowledges and represents that it has not relied on any representation, assertion, guarantee, warranty, collateral contract or other assurance, except those set out in this document.

For additional information on this product or this warranty, contact a GF Customer Service Representative.

NOTES:

- 1) Additional terms and conditions may apply.
- 2) Freight claims must be notated on the appropriate shipping documents and must be made with immediacy. International, federal and state regulations govern specific requirements for freight claims. Failure to abide by those regulations may result in a denial of the freight claim. GF will assist you in filing the freight claim.
- 3) Claims for any short shipment must be made within three (3) days of the invoice date.

GF Health Products, Inc. One Graham-Field Way Atlanta GA 30340-3140 Tel 1-770-368-4700 Fax 1-770-368-2386 www.grahamfield.com

If you have questions regarding a bed's warranty, contact Basic American Medical Products at 1-770-368-4700.



Manufactured by: GF Health Products, Inc. One Graham-Field Way Atlanta GA 30340-3140



1.770.368.4700 Information contained herein is subject to change. The most current and complete product information can be found on our website. www.grahamfield.com









© 2017, GF Health Products, Inc. All Rights Reserved. Basic American Medical Products, Graham-Field, and Matrix are trademarks of GF Health Products, Inc. GF Health Products, Inc. is an ISO 13485 Certified Company.