

# Traditional Charm



*Fine details of the Bedford cloverleaf wood side edge.*

The Bedford Collection draws on the simplicity and safety of rounded corners on top and base and cloverleaf wood side edges to present a warm home-style feel to this collection. Solid wood edge on door and drawer fronts and opulent square Bun wood feet complete the design. High Pressure tops bring a lifetime of durability to this collection. The Bedford Collection, as every Basic American collection, is available in any of our standard woodtones to meet your furnishing needs.



## The Bedford Collection *by Basic American*



Please visit our Long Term Care Social Commentary web site: [basicamericancomfort.com](http://basicamericancomfort.com)

## The Bedford Collection

by Basic American



**Three Drawer  
Bedside Chest**  
W- 21.5", D-17.25", H-31"  
A31-46



**Four Drawer  
Dresser**  
W- 30", D-17.25", H-36.5"  
A37-46



**Two Door  
Two Drawer  
Wardrobe**  
W- 30", D-22", H-78"  
B021-46



**Head & Foot Board**

See Head and Foot Board Options

All BAMP Resident Room furniture is proudly manufactured in factories in the USA. All furniture is designed and built using the most modern CNC (Computer Numerically Controlled) CAD/CAM (Computer Aided Design/Computer Aided Manufacturing) programs. This ensures that each piece retains the ultimate in quality control and universality and that our plants offer the utmost in efficiency and cost containment.

Our furnishings are available in numerous configurations and finishing:

We offer Bedsides in either a Three Drawer Chest or a Door/Drawer Cabinet version.

Dressers are available in Three, Four or Six Drawer (horizontal styles).

All Dressers and Bedsides feature a

vented back to eliminate odor buildup. Wardrobes are available in widths of 6 inch increments from 24" to 48" with no or two drawers (on wardrobes up to 36" wide) and with no or four drawers (on 42" and 48" wide wardrobes).

Wardrobes and Bedsides Cabinets feature a European style hinge which is pocketed into the door and the cabinet to offer superior strength. These hinges are six way adjustable: for Pitch – up and down; Roll – left and right; and Yaw – in and out. Hinges are a "snap in" style which means that doors can be removed without removing the hinges from either the cabinet or the door. Hinges offer a full 110 degree swing and are self closing.

The drawer unit on the Bedford Collection is our standard composite drawer that offers vinyl wrapped protection to make it moisture resistant.

Our standard drawer slide system is a 100 pound test capacity drawer. It also features a self-closing mechanism.

Locks are available for all units, but preferably should be ordered with the initial order. Locks are keyed units with two keys per lock. Locks are generally placed on the top drawer of bedside chests or cabinets and on wardrobe doors. They are ordered per locking unit. Master keys are available if ordered with the initial order.

Special order or sized cases are also available as many times existing facilities have physical barriers which must be "worked around". These may be subject to minimum quantities as they require a substantial amount of preproduction and production program changes.

The Bedford Collection is available in any of our standard finishes



Item Suffix	Surface	Top Edge	Door/Drawer Front Edges	Drawer
-46	Laminate	Wood	Wood	Overlay



1-800-554-9215 Fax 1-800-524-4113  
Please visit our Long Term Care Social Commentary web site:  
basicamericancomfort.com  
View these and more products at [www.grahamfield.com](http://www.grahamfield.com)

© 2009, GF Health Products, Inc.

GF0900241RevA09