

Old World Elegance



Fine details of the Savannahs edges

The Savannah Collection combines a fresh attractive look with old world elegance to create the modern look ideal for resident rooms. Picture frame door and drawer fronts in a contrasting tone present a luxurious styling feature. Contrasting multi-faceted edges mirror the wood edge on the top highlight this collection. Select from any of our standard woodtone offerings to complement any room décor.



The Savannah Collection *by Basic American*



Please visit our Long Term Care Social Commentary web site: basicamericancomfort.com

The Savannah Collection

by Basic American



**Three Drawer
Bedside Chest**
W- 25.5", D-17.25", H-30.5"
A31-52



**Door/Drawer
Bedside Cabinet**
W- 25.5", D-17.25", H-30.5"
A30-52



**Two Door
Two Drawer
Wardrobe**
W- 31", D-23", H-77"
B021-52



Head & Foot Board
See Head and Foot Board
Options

All BAMP Resident Room furniture is proudly manufactured in factories in the USA. All furniture is designed and built using the most modern CNC (Computer Numerically Controlled) CAD/CAM (Computer Aided Design/Computer Aided Manufacturing) programs. This ensures that each piece retains the ultimate in quality control and universality and that our plants offer the utmost in efficiency and cost containment.

Our furnishings are available in numerous configurations and finishing:

We offer Bedsides in either a Three Drawer Chest or a Door/Drawer Cabinet version.

Dressers are available in Three, Four or Six Drawer (horizontal styles).

All Dressers and Bedsides feature a

vented back to eliminate odor buildup. Wardrobes are available in widths of 6 inch increments from 24" to 48" with no or two drawers (on wardrobes up to 36" wide) and with no or four drawers (on 42" and 48" wide wardrobes).

Wardrobes and Bedside Cabinets feature a European style hinge which is pocketed into the door and the cabinet to offer superior strength. These hinges are six way adjustable: for Pitch – up and down; Roll – left and right; and Yaw – in and out. Hinges are a “snap in” style which means that doors can be removed without removing the hinges from either the cabinet or the door. Hinges offer a full 110 degree swing and are self closing.

The drawer unit on the Savannah Collection is our standard composite drawer that offers vinyl wrapped protection to make it moisture resistant.

Our standard drawer slide system is a 100 pound test capacity drawer. It also features a self-closing mechanism.

Locks are available for all units, but preferably should be ordered with the initial order. Locks are keyed units with two keys per lock. Locks are generally placed on the top drawer of bedside chests or cabinets and on wardrobe doors. They are ordered per locking unit. Master keys are available if ordered with the initial order.

Special order or sized cases are also available as many times existing facilities have physical barriers which must be “worked around”. These may be subject to minimum quantities as they require a substantial amount of preproduction and production program changes.

The Savannah Collection is available in any of our standard finishes



Item Suffix	Surface	Top Edge	Door/Drawer Front Edges	Drawer
-52	Laminate	Wood	Wood	Overlay



1-800-554-9215 Fax 1-800-524-4113
Please visit our Long Term Care Social Commentary web site:
basicamericancomfort.com
View these and more products at www.grahamfield.com

© 2009, GF Health Products, Inc.

GF0900247RevA09