

# The Classic From the 1700's



*Optional "Show Top" on Wardrobe*

Elegant vintage styling showcases a timeless design of the furniture industry dating to the 1700's. The Georgetown Collection features flush case sides, overlay drawers and cut-out front kick plate for a detailed base finish. Available with optional three sided plinth base and various top edges and door/drawer edges so that you may customize cases to meet your resident room specifications.



## The Georgetown Collection *by Basic American*



# The Georgetown Collection

by Basic American



Three Drawer  
Bedside Chest  
W- 21", D-18", H-30"  
A31-31



Three Drawer  
Bedside Chest  
W- 21", D-18", H-30"  
A30-31



Four Drawer  
Dresser  
W- 30", D-18", H-34"  
A37-31



Two Door  
Two Drawer  
Wardrobe  
W- 24", D-22", H-78"  
B021-31



Head & Foot Board  
See Head and Foot Board  
Options

All BAMP Resident Room furniture is proudly manufactured in the USA. All furniture is designed and built using the most modern CNC (Computer Numerically Controlled) CAD/CAM (Computer Aided Design/Computer Aided Manufacturing) programs. This ensures that each piece retains the ultimate in quality control and universality and that our plants offer the utmost in efficiency and cost containment.

Our furnishings are available in numerous configurations and finishing:

We offer Bedsides in either a Three Drawer Chest or a Door/Drawer Cabinet version.

Dressers are available in Three, Four or Six Drawer (horizontal styles).

All Dressers and Bedsides feature a vented back to eliminate odor buildup. Wardrobes are available in widths of 6 inch increments from 24" to 48" with no or two drawers (on wardrobes up to 36" wide) and with no or four drawers (on 42" and 48" wide wardrobes).

Wardrobes and Bedside Cabinets feature a European style hinge which is pocketed into the door and the cabinet to offer superior strength. These hinges are six way adjustable: for Pitch – up and down; Roll – left and right; and Yaw – in and out. Hinges are engineered so that doors can be removed without removing the hinges from either the cabinet or the door. Hinges offer a full 110 degree swing and are self closing

The drawer unit on the Georgetown Collection is our standard composite drawer that offers vinyl wrapped

protection to make it moisture resistant. Our standard drawer slide system is a 100 pound test capacity drawer. It also features a self-closing mechanism.

Locks are available for all units, but preferably should be ordered with the initial order. Locks are keyed units with two keys per lock. Locks are generally placed on the top drawer of bedside chests or cabinets and on wardrobe doors. They are ordered per locking unit. Master keys are available if ordered with the initial order.

Special order or sized cases are also available as many times existing facilities have physical barriers which must be "worked around". These may be subject to minimum quantities as they require a substantial amount of preproduction and production program changes.

The Georgetown Collection is available in any of our standard finishes



Kensington Maple

New Age Oak

Solar Oak

Fonthill Pear

Wild Cherry

Windsor Mahogany

Montana Walnut

Figured Mahogany

Item Suffix	Surface	Top Edge	Door/Drawer Front Edges	Drawer	Variations
-31	Laminate	Wood	3 mm Self Edge	Overlay	Cut-Out Front Kick
W-31	Wood	Wood	3 mm Self Edge	Overlay	Cut-Out Front Kick
T-31	Laminate	T-Mold	3 mm Self Edge	Overlay	Cut-Out Front Kick



800.554.9215 Fax 800.524.4113  
View these and more products at [www.grahamfield.com](http://www.grahamfield.com)

Basic American Medical Products is not responsible for typographical errors. All illustrations, specifications, packaging and warranties contained in this literature are based on the latest product information available at the time of printing. The most current product information can be found online at [www.grahamfield.com](http://www.grahamfield.com) © 2012, GF Health Products, Inc.

GF09002443RevB12