

The Practical Solution

The Highlands Collection is a straight and simple styling that provides a practical solution to resident room furnishing. Stylish full three sided plinth base with crescent front cut-out kick plate offers a full dimensional look. This collection is also available in any of our eight standard woodtones to compliment any room décor.



The Highlands Collection *by Basic American*



The Highlands Collection

by Basic American



**Three Drawer
Bedside Chest**
W- 21", D-18", H-30"
A31-25



**Door/Drawer
Bedside Cabinet**
W- 21", D-18", H-30"
A30-25



**Four Drawer
Dresser**
W- 30", D-18", H-34"
A37-25



**Two Door
Two Drawer
Wardrobe**
W- 24", D-22", H-78"
B02-25



Head & Foot Board
See Head and Foot Board
Options

Features of all Basic American casegoods:



Proudly made in the USA.

- ◆ CNC manufacturing ensures consistent quality.
- ◆ Highly resistant to moisture:
 - All edges are completely finished.
 - Drawers are vinyl wrapped and bottoms are sealed.
- ◆ Dowel and cam construction for durability.
- ◆ Rounded edges reduce injury.
- ◆ Drawer stops for safety.
- ◆ Metal drawer slides are tested to 100 pound capacity and feature a self closing mechanism.
- ◆ Ventilated backs promote air flow.
- ◆ Smooth floor guides for ease of movement.
- ◆ Wardrobe floor guides are adjustable for leveling the unit to uneven surfaces.
- ◆ Drawer fronts are separate from the drawer box, simplifying replacement, if necessary.
- ◆ Hardware:
 - European style hinges provide superior strength and adjustability.
 - Doors have hidden hinges.
 - Doors can be removed without removing the hinges from either the door or cabinet.

- Hinges offer a full 110 degree swing and are self closing.
- Fixed drawer and door hardware selections are easy to grasp.

Our furnishings are available in numerous configurations:

- ◆ Bedsides are available as either a Three Drawer Chest or a Door/Drawer Cabinet version.
- ◆ Dressers are available in three, four, or six drawer horizontal styles.
- ◆ Wardrobes are available with one or two doors, and with or without drawers.
- ◆ Locks are available for all units, but preferably should be ordered with the initial order.
 - Keyed units have two keys per lock.
 - Locks are generally placed on the top drawer of a bedside or on wardrobe doors.
 - Master keys are available if ordered with the initial order.

Special Order custom sizes of casegoods are available, but may require minimum quantities and additional production time.

The Highlands Collection is available in any of our standard finishes.



Kensington Maple

New Age OakSolar OakFonthill Pear

Wild Cherry

Shaker Cherry

Windsor Mahogany

Montana Walnut

Figured Mahogany

Cocobala

Item Suffix	Surface	Top Edge	Door/Drawer Front Edges	Drawer
-25	Laminate	T-Mold	3 mm Self Edged	Inset



800.554.9215 Fax 800.524.4113
View these and more products at www.grahamfield.com

Basic American Medical Products is not responsible for typographical errors. All illustrations, specifications, packaging and warranties contained in this literature are based on the latest product information available at the time of printing. The most current product information can be found online at www.grahamfield.com © 2012, GF Health Products, Inc.

GF0900245RevD13