

From The Frank Lloyd Wright Era



*Fine details of the Oak Park
bevel cut wood edges.*

Style reminiscent of Prairie Design from the Frank Lloyd Wright era. Unique raised panel design elements on sides of case add a distinctive flair. Laminate construction with bevel cut wood edges on door, drawer and top. Shot peened matte black hardware completes the stylistic rendering.



The Oak Park Collection *by Basic American*



The Oak Park Collection

by Basic American



Features of all Basic American casegoods:

- Proudly made in the USA.
- ◆ CNC manufacturing ensures consistent quality.
- ◆ Highly resistant to moisture:
 - All edges are completely finished.
 - Drawers are vinyl wrapped and bottoms are sealed.
- ◆ Dowel and cam construction for durability.
- ◆ Rounded edges reduce injury.
- ◆ Drawer stops for safety.
- ◆ Wide cross braces between drawers provide a stronger and more durable unit.
- ◆ Metal drawer slides are tested to 100 pound capacity and feature a self closing mechanism.
- ◆ Ventilated backs promote air flow.
- ◆ Smooth floor guides for ease of movement.
- ◆ Wardrobe floor guides are adjustable for leveling the unit to uneven surfaces.
- ◆ Drawer fronts are separate from the drawer box, simplifying replacement, if necessary.
- ◆ Hardware:
 - European style hinges provide superior strength and adjustability.
 - Doors have hidden hinges.
 - Doors can be removed without removing the hinges from either the door or cabinet.


- Hinges offer a full 110 degree swing and are self closing.
- Fixed drawer and door hardware selections are easy to grasp.

Our furnishings are available in numerous configurations:

- ◆ Bedside are available as either a Three Drawer Chest or a Door/Drawer Cabinet version.
- ◆ Dressers are available in three, four, or six drawer horizontal styles.
- ◆ Wardrobes are available with one or two doors, and with or without drawers.
- ◆ Locks are available for all units, but preferably should be ordered with the initial order.
 - Keyed units have two keys per lock.
 - Locks are generally placed on the top drawer of a bedside or on wardrobe doors.
 - Master keys are available if ordered with the initial order.

Special Order custom sizes of casegoods are available, but may require minimum quantities and additional production time.

The Oak Park Collection is available in any of our standard finishes.



Item Suffix	Surface	Top Edge	Door/Drawer Front Edges	Drawer
-44	Laminate	Wood	Wood	Inset



1-800-554-9215 Fax 1-800-524-4113
View these and more products at www.grahamfield.com

Basic American Medical Products is not responsible for typographical errors. All illustrations, specifications, packaging and warranties contained in this literature are based on the latest product information available at the time of printing. The most current product information can be found online at www.grahamfield.com © 2012, GF Health Products, Inc.

GF0900243RevD13