

# Magnolia Collection

## 3DL Thermoformed Casegoods

*When form and functionality are equally important, 3DL Thermoformed Casegoods combine pleasing aesthetics with durability.*

*These high performance surfaces provide greater resistance to moisture and bacterial penetration and are more resistant to denting, cracking, scuffs and chipping..*



Proudly made in the USA

## Casegood Construction



Seamless tops, drawers, and door fronts are easier to clean.

Drawer fronts are separate from the drawer box, simplifying replacement, if necessary.

Drawer construction includes dowels and staples on sides with an additional bead of glue along perimeter of drawer bottom.



Dressers and bedside cabinets have a stile across the back and between each drawer for structural support.

Self-closing drawers have metal drawer slides that are tested to 100 lb capacity per drawer and have drawer stops for safety. Drawers are easily removable by lifting up over the glides.

Ventilated backs of bed sides and dressers promote airflow.

All units have smooth floor glides for ease of movement.

All bed sides, dressers, and wardrobes have a full bottom board for structural support.

European-style hinges provide superior strength and adjustability. Doors can be removed without removing hinges from either the door or cabinet. Hidden hinges offer 110 degree swing and are self-closing.

Wardrobe clothes bar height is adjustable.

Wardrobes have two stiles across the back for added structural support. We can also supply a gap-filler, if requested, so that the wardrobes can be attached to the wall.

All bed sides, dressers, and wardrobes have a full bottom board for structural support.

All units have smooth floor glides for ease of movement.

Wardrobes provide four top access points to the 4" levelers for easy adjustment with a screw driver or socket ratchet to accommodate uneven floor surfaces.

Optional locks are available for all units. Locks are generally placed on the top bedside drawer or on wardrobe doors. Two keys are provided per lock. Master keys are available with initial order.



**Five year limited warranty**

# Magnolia Collection

## Design Specifications



Three Drawer  
Bedside Chest  
A31-34



Four Drawer  
Dresser  
A37-34



Two Door, Two  
Drawer Wardrobe  
B021-34



Mitered crown solid kickplate



Square profile on wardrobe doors

Square profile on every drawer



Profile edge detail



Ogee door/drawer edge detail

Special Order custom sizes of casegoods are available.

## Nominal Dimensions for Casegoods

	Door/Drawer Bedside Cabinet <b>A30-34</b> W-21", D-18", H-30"
	Three Drawer Bedside Chest <b>A31-34</b> W-21", D-18", H-30"
	Three Drawer Dresser <b>A36-34</b> W-30", D-18", H-30"
	Four Drawer Dresser <b>A37-34</b> W-30", D-18", H-36"
	Side-by-Side Six Drawer Dresser <b>A371-34</b> W-42", D-18", H-30"
	Two Door Wardrobe <b>B01-34</b> W-24", D-22", H-76" <b>B011-34</b> W-30", D-22", H-76" <b>B012-34</b> W-36", D-22", H-76" <b>B013-34</b> W-42", D-22", H-76" <b>B014-34</b> W-48", D-22", H-76"
	Two Door, Two Drawer Wardrobe <b>B02-34</b> W-24", D-22", H-76" <b>B021-34</b> W-30", D-22", H-76" <b>B022-34</b> W-36", D-22", H-76"
	Two Door, Side-by-Side Four Drawer Wardrobe <b>B023-34</b> W-42", D-22", H-76" <b>B024-34</b> W-48", D-22", H-76"
	Armoire, 4 Drawer <b>B021TV-34</b> W-30", D-23", H-66"

## Casegood Hardware Selections:



Bow Pull (Chrome)



Bow Pull (Antique Brass)



Fluted Column Pull (Brushed Silver)



Bolt Strap Pull (Brushed Silver)



Bolt Strap Pull (Antique Brass)



Bolt Strap Pull (Oil Rubbed Bronze)



Bar Pull (Antique Brass)



Rope Pull (Brushed Silver)



Rope Pull (Antique Brass)



Banded Pull (Pewter)



Bone (Antique Brass)



U Pull (Chrome)



Half Moon (Satin Nickel)



Black Bar Pull



Continental (Antique Brass)

## 3DL Thermoformed Finishes:



Kensington Maple

Solar Oak

Wild Cherry

Windsor Mahogany

Shaker Cherry



Cocobala

Talas Cherry

Aria

Arctic Groovz

### Material Performance Standards

Scratch Resistance: Hoffman Method \_\_\_\_\_ 1300g

Wear: NEMA Wear Resistance LD3-2005/3.13 \_\_\_\_\_ 750 cycles

Impact: NEMA Ball Impact LD3-2005/3.8 \_\_\_\_\_ 3000m

Stain Resistance: water, coffee, tea, vegetable/  
olive oil, ketchup, mustard, vinegar, 10% citric juices

**1.678.201.3200 Fax 1.770.368.4954**

Information contained herein is subject to change.

The most current and complete product information can be found on our website.

**[www.grahamfield.com](http://www.grahamfield.com)**

Follow us on   

© 2016, GF Health Products, Inc. All Rights Reserved.

Basic American Medical Products is a trademark of GF Health Products, Inc.

GF Health Products, Inc. is an ISO 13485 Certified Company. GF1500085RevC17

